Registration and Changes of Aircraft Information

Table of Contents

01. Flow of Registration and Changes (Update/Deletion) of Aircraft Information 1/2

The following shows the flow when newly registering Aircraft Information using this system.

Start Procedures to Register Aircraft Information

⬇

Select Registration and Changes to Aircraft Information

Select the "Register and Change Aircraft Information" button in the Main Menu.

⬇

Select New Registration

Select the "New Registration" button in the Aircraft Information List.

⬇

Register the Aircraft

Enter information relating to the aircraft on the Enter Aircraft Information screen.

⬇

Aircraft Information Registration is Complete

01. Flow of Registration and Changes (Updates and Deletion) of Aircraft Information 2/2

The following shows the flow when updating or deleting Aircraft Information using this system.

Start Procedures to Change (Update/Delete) Aircraft Information

Select Registration and Changes of the Aircraft Information

Select the "Register and Change Aircraft Information" button Main Menu.

(For Updating Aircraft Information)

Select the Aircraft Information to Update

Select the aircraft targeted for update in the Aircraft Information List and then select the "Update/Delete" button.

Update the Aircraft Information

Update information relating to the aircraft on the Enter Aircraft Information screen.

Updating Procedures for Aircraft Information are Completed

(For Deleting Aircraft Information)

Select the Aircraft Information to Delete

Select the aircraft targeted to be deleted in the Aircraft Information List, and then select the "Update/Delete" button.

Delete the Aircraft Information

Select the "Delete" button on the Aircraft Information input screen.
* If the aircraft targeted for deletion is included in the submitted application, or the like, it will not be displayed on the [Select Aircraft Information] screen, in the additional procedure for continued applications and the like, and you will not be able to continue the application. Furthermore, the aircraft will also not be displayed on the [Aircraft Information List] screen.
* Data that has been deleted cannot be recovered.

Deletion Procedures for Aircraft Information are Completed

02. New Registration of Aircraft Information [Select Registration and Changes of Aircraft]

Open the [Aircraft Information List] screen from the [Main Menu] screen.

(1) In the [Main Menu] screen, press 航空機情報の登録・変更
in the heading [Preparation of Information Necessary for Application
for Permission (Notification)].

The [Aircraft Information List] screen opens.

03. New Registration of Aircraft Information [Select New Registration]

Implement a new registration for an aircraft in the [Aircraft Information List].

(1) Press 新規登録 in the [Aircraft Information List] screen.

The [Aircraft Information Input] screen opens.

04. New Registration of Aircraft Information [Register an Aircraft]

Enter information relating to the aircraft in the [Aircraft Information Input] screen.

Enter information relating to the aircraft in the Aircraft Information Input] screen.

(1) Type of Aircraft
Select the type of aircraft from the pull-down menu (below).
[Airplane/Rotorcraft/Glider/Airship/Ultralight Aircraft and Others (Airplane)/Gyroplane (Rotor Wings)]

(2) Model Name (Selection)
(2)-1 Select from the models registered in the system.
You narrow down the list by selecting the type of aircraft.
If the model name is different with the same model ID, it is the same model.
* If you enter the first half of the model name, predicted candidates are displayed in the pull-down menu.
* The number (xx) at the beginning of the model name is the model ID managed by the system.
The same numbers indicate the same model.
(2)-2 If the model name corresponding to (2)-1 does not exist, select "If there is no model corresponding to the above," and enter the model name directly in the field below.
You can enter up to 100 characters.
Names cannot be entered using double-byte characters.
(When entering using alphanumeric characters, use single-byte characters.)
A space cannot be entered in the model name.

(3) Aircraft Nationality and Registration Mark
Enter the aircraft nationality and registration mark.
Names cannot be entered using double-byte characters.
(When entering using alphanumeric characters, use single-byte characters.)
A space cannot be entered in the aircraft nationality and registration mark.
You can enter up to 12 characters

(4) If there is no problem with the entered content, press 登録 .
A dialog box is displayed to check the aircraft registration.

(5) Press OK to register information about the aircraft.
After completing the registration, the [Aircraft Information List] screen is displayed.
* The same information as an already registered aircraft (all items) cannot be registered or updated.

05. Update/Deletion of Aircraft Information [Select Registration and Changes of Aircraft]

Open the [Aircraft Information List] screen from the [Main Menu] screen.

(1) In the [Main Menu] screen, press ［航空機情報の登録・変更］ in the heading [Preparation of Information Necessary for Application for Permission (Notification)].

The [Aircraft Information List] screen opens.

06. Update/Deletion of Aircraft Information [Select the Aircraft to Update/Delete]

[Select the aircraft targeted to be updated/deleted in the [Aircraft Information List] screen.

The registered aircraft is displayed in the list.
Also, if there are more than 21 cases, they will be displayed on multiple pages.

(1) When searching for an aircraft, enter and select [Aircraft ID], [Aircraft Type], [Model Name], [Aircraft Nationality and Registration Marks], and the like, and press 検索 to display the corresponding aircraft.

(2) From the list, press 更新/削除 for the aircraft that you want to update/delete.

The [Aircraft Information Input] screen is displayed.

07. Update of Aircraft Information [Update an Aircraft]

Update information relating to the aircraft on the [Aircraft Information Input] screen.

Information relating to the aircraft selected in the [Aircraft Information List] is displayed.
Also, the input method for each item is the same as "04. New Registration of Aircraft Information [Register an Aircraft]."

(1) Update Date and Time:
   The date and time of the update of information relating to an aircraft is displayed.

(2) Aircraft ID
   This is the system ID that uniquely identifies the aircraft.

(3) If there is no problem with the entered content, press [更新] .
   A dialog box is displayed to check the update of the Aircraft Information.

(4) Press [OK] to update information relating to the aircraft.
   * The same information as an already registered aircraft cannot be registered or updated.

08. Deletion of Aircraft Information [Delete Aircraft]

Delete information relating to the aircraft in the [Aircraft Information Input] screen.

Information relating to the aircraft selected in the [Aircraft Information List] is displayed.

(1) If there is no problem with target to be deleted, press 削除 .
A dialog box is displayed to check the deletion of the aircraft.

(2) Press OK to delete information about the aircraft.
* If the aircraft targeted for deletion is included in the submitted application, or the like, it will not be displayed on the [Select Aircraft Information] screen, in the additional procedure for continued applications and the like, and you will not be able to continue the application.
Furthermore, the aircraft will also not be displayed on the [Aircraft Information List] screen.
* Data that has been deleted cannot be recovered.
* You can register a new aircraft with the same information as the deleted aircraft.

Registration and Changes of Pilot Information

Table of Contents

The following shows the flow when newly registering pilot information using this system.

Start Procedures to Register Pilot Information

⬇

Select Registration and Changes of Pilot Information

Select the "Register and Change Pilot Information" button in the main menu.

⬇

Select New Registration

Select the "New Registration" button in the Pilot Information List.

⬇

Register the Pilot

Enter information relating to the pilot on the Enter Pilot Information screen.

⬇

**Registration of Pilot Information is Completed**

01. Flow of Registration and Changes (Update/Deletion) of Pilot Information 2/2

The following shows the flow when updating or deleting pilot information using this system.

Start Procedures to Update (Update/Delete) Pilot Information

Select Registration and Changes of the Pilot Information

Select the "Register and Change Pilot Information" button in the main menu.

(For Updating Pilot Information)

Select the Pilot Information to Update

Select the pilot targeted for update in the Pilot Information List and then select the "Update/Delete" button.

Update the Pilot

Update information relating to the pilot on the Pilot Information Input screen.

Updating Procedures for Pilot Information are Completed

(For Deleting Pilot Information)

Select the Pilot Information to Delete

Select the pilot targeted to be deleted in the Pilot Information List, and then select the "Update/Delete" button.

Delete the Pilot

Select the "Delete" button in the Pilot Information Input screen.
* If the pilot targeted for deletion is included in the submitted application, or the like, it will not be displayed on the [Select Pilot Information] screen, in the additional procedure for continued applications and the like, and you will not be able to continue the application. Furthermore, the pilot information will also not be displayed in the [Pilot Information List] screen.
* Data that has been deleted cannot be recovered.

Deletion Procedures for Pilot Information are Completed

02. New Registration of Pilot Information [Select Registration and Changes of Passenger]

Open the [Pilot Information List] screen from the [Main Menu] screen.

(1) In the [Main Menu] screen, press 操縦者情報の登録・変更 in the heading [Preparation of Information Necessary for Application for Permission (Notification)].

The [Pilot Information List] screen opens.

03. New Registration of Pilot Information [Select New Registration]

Implement a new registration for a pilot in the [Pilot Information List].

(1) Press 新規登録 in the [Pilot Information List] screen.

▼

The [Enter Pilot Information] screen opens.

04. New Registration of Pilot Information [Register a Pilot]

Enter information relating to the pilot on the [Pilot Information Input] screen.

Enter information relating to the pilot in the [Pilot Information List] screen.

(1) Name of the Pilot
   Enter the name of the pilot. (Enter a double-byte space between the first and last names.)
   Names cannot be entered using double-byte characters.
   (When entering using alphanumeric characters, use single-byte characters.)
   You can enter up to 128 characters.

(2) Qualifications Held
   Select the qualifications held by the pilot from the pull-down list (below).
   [Airline Transport/Commercial/Private/Permission in Article 28/Others]
   If you have multiple qualifications and want to register multiple qualifications for the pilot information, register the pilot information separately for each qualification.

(3) Number of the Technical Certificate(Optional)
   Enter the number of the technical certificate for the qualification held by the pilot.
   Names cannot be entered using double-byte characters.
   (Alphanumeric characters must be single-byte characters.)
   You can enter up to 9 characters.

(4) Limited Items (Optional)
   Enter limited items for qualifications held by the pilot.
   Names cannot be entered using double-byte characters.
   (When entering using alphanumeric characters, use single-byte characters.)
   You can enter up to 200 characters.

(5) If there is no problem with the content entered , press 登録 .
   A dialog box is displayed to check pilot registration.

(6) Press OK to register information relating to the pilot.
   After completing the registration, the [Pilot Information List] screen is displayed.
   * The same information as an already registered pilot (all items) cannot be registered or updated.

05. Update/Deletion of Pilot Information [Select Registration and Changes of Pilot]

Open the [Pilot Information List] screen from the [Main Menu] screen.

(1) In the [Main Menu] screen, press 操縦者情報の登録・変更
in the heading [Preparation of Information Necessary for
Application for Permission (Notification)].

The [Pilot Information List] screen opens.

06. Update/Deletion of Pilot Information [Select the Pilot Information to Update/Delete]

Select the pilot targeted to be updated/deleted in the [Pilot Information List] screen.

The registered pilot is displayed in the list.
Also, if there are more than 21 cases, they will be displayed on multiple pages.

(1) When searching for a pilot information, enter and select the [Pilot ID], [Name of the Pilot], [Qualifications Held], [Number of the Technical Certificate], and the [Limited Items] or the like. Then press 検索 and the corresponding pilot is displayed.

(2) From the list, press 更新/削除 of the pilot that you want to update/delete.

The [Pilot Information Input] screen is displayed.

07. Update of Pilot Information [Update a Pilot]

Update information relating to the pilot on the [Pilot Information Input] screen.

Information of the pilot selected in the [Pilot Information List] is displayed.
 Same as "04. New Registration of Pilot Information [Register a Pilot]"

(1) Update Date and Time:
   The date and time of the registration or update of information relating to the pilot is displayed.

(2) Passenger ID
   This is the system ID that uniquely identifies the pilot.

(3) If there is no problem with the entered content,
   press 更新 .
   A dialog box is displayed to check the update of the pilot.

(4) Press OK to update information relating to the pilot.

   * The same information as an already registered pilot (all items) cannot be registered or updated.

08. Deletion of Pilot Information [Delete Pilot Information]

Delete information relating to the pilot on the [Pilot Information Input] screen.

Information of the pilot selected in the [Pilot Information List] is displayed.

(3) If there is no problem with target to be deleted, press 削除 .
   A dialog box is displayed to check the deletion of the pilot.

(2) Press OK to delete information relating to the pilot.
   * If the pilot targeted for deletion is included in the submitted application, or the like, it will not be displayed on the [Select] screen, in the additional procedure for continued applications and the like, and you will not be able to continue the application. Furthermore, the pilot information will also not be displayed in the [Pilot Information List] screen.
   * Data that has been deleted cannot be recovered.
   * You can register a new pilot information with the same information as the deleted pilot.

Registration and Changes of Fellow Passenger Information

Table of Contents

The following shows the flow when newly registering fellow passenger information using this system.

Start Procedures to Register Fellow Passenger Information

⬇

Select Registration and Changes of Fellow Passenger Information

Select the "Register and Change Fellow Passenger Information" button in the main menu.

⬇

Select New Registration

Select the "New Registration" button in the Fellow Passenger Information List.

⬇

Register the Fellow Passenger

Enter information relating to the fellow passengers on the input screen for fellow passenger information.

⬇

Registration of Fellow Passenger Information is Completed

01. Flow of Registration and Changes (Update/Deletion) of Fellow Passenger Information 2/2

The following shows the flow when updating or deleting fellow passenger information using this system.

Start Procedures to Update (Update/Delete) Fellow Passenger Information

Select Registration and Changes of the Fellow Passenger Information

Select the "Register and Change Fellow Passenger Information" button in the main menu.

(For Updating Fellow Passenger Information)

Select the Fellow Passenger Information to Update

Select the fellow passenger targeted for update in the Fellow Passenger Information List and then select the "Update/Delete" button.

Update the Fellow Passenger Information

Update the information relating to the fellow passenger on the input screen for fellow passenger information.

Updating Procedures for Fellow Passenger Information are Completed

(For Deleting Fellow Passenger Information)

Select the Fellow Passenger Information to Delete

Select the fellow passenger targeted to be deleted in the Fellow Passenger Information List, and then select the "Update/Delete" button.

Delete the Fellow Passenger Information

Select the "Delete" button in the Fellow Passenger Information input screen.
* If the fellow passenger targeted for deletion is included in the submitted application, or the like, it will not be displayed on the [Select Fellow Passenger Information] screen, in the additional procedure for continued applications and the like, and you will not be able to continue the application.
  Furthermore, the fellow passenger information will also not be displayed in the [Fellow Passenger Information List] screen.
* Data that has been deleted cannot be recovered.

Deletion Procedures for Fellow Passenger Information are Completed

02. New Registration of Fellow Passenger Information [Select Registration and Changes of Fellow Passenger]

Open the [Fellow Passenger Information List] screen from the [Main Menu] screen.

(1) In the [Main Menu] screen, press 同乗者情報の登録・変更 in the heading [Preparation of Information Necessary for Application for Permission (Notification)].

The [Fellow Passenger Information List] screen opens.

03. New Registration of Fellow Passenger Information [Select New Registration]

Implement a new registration for a fellow passenger in the [Fellow Passenger Information List].

(1) Press 新規登録 in the [Fellow Passenger Information List] screen.

The [Enter Fellow Passenger Information] screen opens.

04. New Registration of Fellow Passenger Information [Register a Fellow Passenger]

Enter information relating to the fellow passengers on the [Enter Fellow Passenger Information] screen.

Enter information relating to the fellow passengers in the [Fellow Passenger Information List] screen.

(1) Name of Fellow Passenger
Enter the name of fellow passenger. (Enter a double-byte space between the first and last names.)
Names cannot be entered using double-byte characters.
(When entering using alphanumeric characters, use single-byte characters.)
You can enter up to 128 characters.

(2) Purpose of Flight
Enter the purpose for being a fellow passenger.
Names cannot be entered using double-byte characters.
(When entering using alphanumeric characters, use single-byte characters.)
You can enter up to 200 characters.

(3) If there is no problem with the entered content, press 登録
A dialog box is displayed to check fellow passenger registration.

(4) Press OK to register information relating to the fellow passenger.
After completing the registration, the [Fellow Passenger Information List] screen is displayed.
* The same information as an already registered fellow passengers (all items) cannot be registered or updated.

05. Update/Deletion of Fellow Passenger Information [Select Registration and Changes of Fellow Passenger]

Open the [Fellow Passenger Information List] screen from the [Main Menu] screen.

(1) In the [Main Menu] screen, press 同乗者情報の登録・変更 in the heading [Preparation of Information Necessary for Application for Permission (Notification)].

The [Fellow Passenger Information List] screen opens.

06. Update/Deletion of Fellow Passenger Information [Select the Fellow Passenger to Update/Delete]

[Select the fellow passenger targeted to be updated /deleted in the [Fellow Passenger Information List] screen.

The registered fellow passenger is displayed in the list.
Also, if there are more than 21 cases, they will be displayed on multiple pages.

(1) When searching for a fellow passenger, enter the [Fellow Passenger ID], [Name of Fellow Passenger] or [Purpose of Flight] or the like, and select it. Then press 検索 and the corresponding fellow passenger is displayed.

(2) From the list, press 更新/削除 of the fellow passenger for whom to implement the update procedure.

[Enter Fellow Passenger Information] screen is displayed.

07. Update of Fellow Passenger Information [Update a Fellow Passenger]

Update the information relating to the fellow passenger on the [Enter Fellow Passenger Information] screen.

Information relating to the fellow passenger selected in the [Fellow Passenger Information List] is displayed.
Also, the input method for each item is the same as "04. New Registration of Fellow Passenger Information [Register a Fellow Passenger]."

(1) Update Date and Time:
   The date and time of the update of information relating to the fellow passenger is displayed.

(2) Fellow Passenger ID
   This is the system ID that uniquely identifies the fellow passenger.

(3) If there is no problem with the entered content,
   press 　更新　 .
   A dialog box is displayed to check the update of the fellow passenger.

(4) Press 　OK　 to update information relating to the fellow passenger.
   * The same information as an already registered fellow passengers (all items) cannot be registered or updated.

08. Deletion of Fellow Passenger Information [Delete a Fellow Passenger]

Delete information relating to the fellow passenger on the [Enter Passenger Information] screen.

Information relating to the fellow passenger selected in the [Fellow Passenger Information List] is displayed.

(1) If there is no problem with target to be deleted, press 削除 .
A dialog box is displayed to check the deletion of the fellow passenger.

(2) Press OK to delete information relating to the fellow passenger.

* If the fellow passenger targeted for deletion is included in the submitted application, or the like, it will not be displayed on the [Select Fellow Passenger Information] screen, in the additional procedure for continued applications and the like, and you will not be able to continue the application.
Furthermore, the fellow passenger will also not be displayed in the [Fellow Passenger Information List] screen.
* Data that has been deleted cannot be recovered.
* You can register a new passenger information with the same information as the deleted passenger.

Registration and Changes of Take-off and Landing Area

Aircraft-Operation-Information-Processing System   Operation Manual

MLIT
Ministry of Land, Infrastructure, Transport and Tourism

Table of Contents

The following shows the flow when newly registering the take-off and landing area using this system.

Start Procedures to Register Take-off and Landing Area

⬇

Select Register and Change the Take-off and Landing Area

Select the "Register and Change the Take-off and Landing Area" button in the Main Menu.

⬇

Select New Registration

Select the "New Registration" button in the Take-off and Landing Area List.

⬇

Register and the Take-off and Landing Area

Enter information relating to the take-off and landing area in the Take-off and Landing Area Input screen.

⬇

Registration of the Take-off and Landing Area is Completed

The following shows the flow when updating or deleting the take-off and landing area using this system.

Start Procedures to Change (Update/Delete) take-off and landing area

Select Registration and Changes of the Take-off and Landing Area

Select the "Register and Change Take-off and Landing Area" button in the Main Menu.

(For Updating Take-off and Landing Area)

Select the Take-off and Landing Area to Update

Select the take-off and landing area targeted for update in the Take-off and Landing Area List and then select the "Update/Delete" button.

Update the Take-off and Landing Area

Update information relating to the take-off and landing area in the Take-off and Landing Area Input screen.

Updating Procedures for Take-off and Landing Area are Completed

(For Deleting Take-off and Landing Area)

Select the Take-off and Landing Area to Delete

Select the take-off and landing area targeted to be deleted in the Take-off and Landing Area List, and then select the "Update/Delete" button.

Delete the Take-off and Landing Area

Select the "Delete" button on the Take-off and Landing input screen.
* If the take-off and landing area targeted for deletion is included in the submitted application, or the like, it will not be displayed on the [Select Take-off and Landing Area Information] screen, in the additional procedure for continued applications and the like, and you will not be able to continue the application.
Furthermore, the take-off and landing area will also not be displayed on the [Take-off and Landing Information List] screen.
* Data that has been deleted cannot be recovered.

Deletion Procedures for Take-off and Landing Area are Completed

02. New Registration of Take-off and Landing Area [Select Registration and Changes of the Take-off and Landing Area]

Open the [Take-off and Landing Area List] screen from the [Main Menu] screen.

(1) In the [Main Menu] screen, press 離着陸場所の登録・変更 in the heading [Preparation of Information Necessary for Application for Permission (Notification)].

The [Take-off and Landing Area List] screen opens.

03. New Registration of Take-off and Landing Area [Select New Registration]

Implement a new registration for the take-off and landing area in the [Take-off and Landing Area List].

(1) Press 　新規登録　 in the [Take-off and Landing Area List] screen.

The [Take-off and Landing Area Input] screen opens.

Enter information relating to the take-off and landing area in the [Take-off and Landing Area Input] screen.

Enter information relating to the take-off and landing area in the [Take-off and Landing Area Input] screen.

(1) Name
   Enter the name of the take-off and landing area.
   Names cannot be entered using double-byte characters.
   (When entering using alphanumeric characters, use single-byte characters.)
   You can enter up to 128 characters.

(2) Name in Furigana
   Furigana (pronunciation) of the take-off and landing area name can be entered using double-byte katakana, double-byte or single-byte spaces, and symbols (ー, ・ ,〜).
   You can enter up to 128 characters.

(3) Address
   (3)-1 Select "Prefecture," and enter the address including the street number below the municipality.
      You can enter up to 364 characters.

   (3)-2 When taking off and landing from the territorial sea or the open seas, check one of that applies, and enter details in the right column.
      You can enter up to 100 characters in the details field.

Enter information relating to the take-off and landing area in the [Take-off and Landing Area Input] screen. (Continued)

(4) 緯度   度   分   秒
   *半角文字、60進法（入力例：35度39分29秒）

(5) 経度   度   分   秒
   *半角文字、60進法（入力例：135度44分29秒）

(6) 種別（必須）   選択してください   ▼

   土地所有者（又は土地管理者）   (7)-1
   *全角英数字入力不可、文字数128文字以下

   土地所有者（又は土地管理者）   (7)-2
   連絡先
   *文字数128文字以下

   離着陸の時間帯（必須）   ● 終日
                      ○ 以下の時間帯で飛行します
                        ・ ▼ ・ ▼ ～ ・ ▼ ・ ▼ ☑ 夜間を含む
                        ※夜間に飛行する場合には必ずチェックしてください。

   灯火施設   設置する灯火施設にチェックしてください。灯火施設の設置基準はこちらを参照ください。
            ☐ 飛行場灯台
            ☑ 風向灯（必須）
            ☐ 着陸区域照明灯
            ☑ 境界灯（必須）
            ☐ 境界誘導灯

   戻る   登録

(4) Latitude (Optional)
   Enter the latitude of the take-off and landing area using single-byte symbols.
   Enter an integer in the range of -90 to 90 for the latitude (degrees).
   Enter an integer in the range of -59 to 59 for the latitude (minutes).
   Enter in the range from -59.999 to 59.999, using a range of 2 digits of integers and 3 digits for decimals for the latitude (seconds).
   It is possible to enter the latitude (seconds) by omitting decimals or lower.

(5) Longitude (Optional)
   Enter the longitude of the take-off and landing area using single-byte symbols.
   Enter an integer in the range of -180 to 180 for the longitude (degrees).
   Enter an integer in the range of -59 to 59 for the longitude (minutes).
   Enter in the range from -59.999 to 59.999, using a range of 2 digits of integers and 3 digits for decimals for the longitude (seconds).
   It is possible to enter the longitude (seconds) by omitting decimals or lower.

(6) Type
   Select the type of the take-off and landing area from the pull-down list (below).
   [Above Ground (General)/Above Ground (Special Area)/Above Ground (Disaster Prevention Response)/Buildings (General)/Structures Other than Buildings (General)/Structures Other than Buildings (Special Areas)/Above Ground (Routes)/Buildings (Routes)]

(7) Landowner (or Land Manager) (Optional)
   (7)-1 Enter the Landowner (or Land Manager) Name of
        the Take-off and Landing Area.Double-byte characters cannot be used.
        (When entering using alphanumeric characters, use single-byte characters.)
        You can enter up to 128 characters.

   (7)-2 Enter the Landowner (or Land Manager)
        Contact (Telephone Number) (Double-byte characters cannot be used.)
        You can enter up to 128 characters.

04. New Registration of Take-off and Landing Area [Register the Take-off and Landing Area] 3/3

Enter information relating to the take-off and landing area in the [Take-off and Landing Area Input] screen. (Continued)

(8) Time Zone at Take-off and Landing Area
Select "All Day" to implement take-off and landing during all hours.
When taking off and landing at a certain time,
select from sunrise/sunset/00:00 to 23:00 (every 1 hour), 00 minutes to 55 minutes (every 5 minutes).

Also, if the take-off and landing time zone includes nighttime, always select "Includes Nighttime."

* If you select All Day, "Includes Night" is automatically checked.

(9) Lighting Facilities
If the take-off and landing time zone includes nighttime, select the installed lighting facilities.
If "Includes Night" is selected in the take-off and landing time zone, wind direction indicator light/boundary light is automatically selected .
If "Includes Nighttime" is not selected in the take-off and landing time zone, you cannot select a lighting facility.

(10) If there is no problem with the content entered,
press 登録 .
A dialog box is displayed to check the take-off and landing area registration.

(11) Press OK to register information relating to the take-off and landing area.
After completing the registration, the [Take-off and Landing Area List] screen is displayed.

05. Update/Deletion of Take-off and Landing Area [Select Registration and Changes of Take-off and Landing Area]

Open the [Take-off and Landing Area List] screen from the [Main Menu] screen.

(1) In the [Main Menu] screen, press 離着陸場所の登録・変更 in the heading [Preparation of Information Necessary for Application for Permission (Notification)].

The [Take-off and Landing Area List] screen opens.

06. Update/Deletion of Take-off and Landing Area [Select Update and Deletion of the Take-off and Landing Area]

[Select the take-off and landing area targeted to be updated/deleted in the [Take-off and Landing Area List] screen.

The registered take-off and landing area is displayed in the list. Also, if there are more than 21 cases, they will be displayed on multiple pages.

(1) When searching for the takeoff and landing area, enter and select the [Off-site ID], [Name], [Address], and [Type], and the like. When you press 検索 , the corresponding takeoff and landing area is displayed.

(2) From the list, press 更新/削除 for the take-off and landing area that you want to update/delete.

The [Take-off and Landing Area Input] screen is displayed.

Update information relating to the take-off and landing area in the [Take-off and Landing Area Input] screen.

Information relating to the take-off and landing area selected in the [Take-off and Landing Area List] is displayed.
Also, the input method for each item is the same as "04. New Registration of Take-off and Landing Area [Register the Take-off and Landing Area]."

(1) Update Date and Time
    The date and time of the registration or update of information relating to the take-off and landing area is displayed.

(2) Off-site ID
    This is the system ID that uniquely identifies the take-off and landing area.

07. Update of Take-off and Landing Area [Update the Take-off and Landing Area] 2/2

Update the take-off and landing area in the [Take-off and Landing Area Input] screen. (Continued)

(3) If there is no problem with the content entered ,
press 更新 .
A dialog box is displayed to check the update of the take-off and landing area.

(4) Press OK to update information relating to the take-off and landing area.

08. Deletion of Take-off and Landing Area [Delete the Take-off and Landing Area]

Delete information relating to the take-off and landing area in the [Take-off and Landing Area Input] screen.

Information relating to the take-off and landing area selected in the [Take-off and Landing Area List] is displayed.

(1) If there is no problem with target to be deleted, press 削除 .
A dialog box is displayed to check the deletion of the take-off and landing area.

(2) Press OK to delete information relating to the take-off and landing area.
  * If the take-off and landing area targeted for deletion is included in the submitted application, or the like, it will not be displayed on the [Select Take-off and Landing Area Information]] screen, in the additional procedure for continued applications and the like, and you will not be able to continue the application.
  Furthermore, the take-off and landing area will also not be displayed on the [Take-off and Landing Information List] screen.
  * Data that has been deleted cannot be recovered.
  * You can register new take-off and landing Area with the same information as the deleted take-off and landing Area .